

At NEO, we design trailers without Weight Distribution in mind. Properly setting up the load is paramount.

To Start:

1. 8-12% tongue weight
2. Tongue height slightly above Level as it travels down the road.

If the above steps have been taken, the following may be done to achieve more stability naturally:

1. Increase tongue Height.
2. Increase tongue Weight.

If any of the above steps cause too much stress on the tow vehicle, upgrade.

